

Cart Cover

Installation Instructions

by Llama Hardware



With Shafts Attached

1. With shafts parallel to the ground, insert the shafts through the Velcro opening. Openings are in the center of the length, so it doesn't matter which way it is put on. Tip the cart on its back to rest on the rubber bumpers to finish installation. Seal the Velcro around the shafts.
2. Connect the two black plastic hooks to each other between the wheel and the frame on each side.
3. Pull the drawstring tightly while fitting the cover around the edges of the seat and oak boards.
4. Fasten the side release buckles on each side and pull the loose end of the webbing taut.



With Shafts Detached

Tip cart on its back. Place the sealed Velcro openings over the areas where the shafts attach. Follow steps 2-4 above.



5. If transporting in the back of a pickup, take the time to make the cover taut in all directions by pulling hard on the draw cords and moving the cord lock against the grommet. Fasten the side release buckles on each side and pull the webbing taut. Use the 9' x 1" web around the middle to further tighten the cover to prevent it from flapping in the wind.
6. Face the top of the cart towards the front of the truck for best results.



Top of cart facing forward

If you have any questions about the use of the cart cover or suggestions for improvement, please contact Barb Brady at 509-238-2998 or barb@llamahardware.com. Your satisfaction with Llama Hardware products is guaranteed.